



Monroe Electronics Telephone Override Instructions Emergency Alert System (EAS)

“For use by authorized personnel only”

1. Make sure there is an analog telephone line connected to the Telephone Override module part number 988. This unit is located in close proximity to the OneNet Encoder.
2. Dial the analog phone number to connect to the Telephone Override unit.
3. Listen to the prompt and enter your passcode.
4. At the next short attention signal press the pound sign (#).
5. You will hear several alert tones followed by a steady 10 second burst. At the end of this burst you have up to two minutes to record your message.
6. Record your message speaking clearly and with a steady tone.
7. When you have finished recording your message press the pound sign (#) and hang up the telephone.

Please note:

Be prepared. Have your message in written form prior to activating the system and recording your message. Once you start your broadcast there are not pauses or cancellation during the live broadcast.

The alert will continue for the pre-programmed time. Typically this would be five broadcast alerts with a minute and 30 seconds between broadcast. Your system may be configured differently.

As of 10/05/07